

ONIX

**Catálogo Colección
Enero '25**



VISION TECH



MODEL:OX02
SIZE:49-18-142

■ COLOR DISPLAY



C1 shiny gold/green



C2 shiny gun/orange



C3 shiny gold/purple



MODEL:OX03
SIZE:50-19-142

■ COLOR DISPLAY



C1 shiny gold/black



C2 shiny pink/black/demi



C3 shiny gun/red



MODEL:OX04
SIZE:53-17-140

■ COLOR DISPLAY



C1 shiny pink demi



C2 shiny silver/brown demi



C3 shiny gun/red



MODEL:OX05
SIZE:53-18-140

■ COLOR DISPLAY



C1 shiny purple/gold



C2 shiny blue/gun



C3 shiny pink/demi



MODEL:OX06
SIZE:51-18-140

■ COLOR DISPLAY



C1 shiny pink/gold/mix



C2 shiny blue/silver/mix



C3 shiny purple/gold/mix



MODEL:OX08
SIZE:54-16-140

■ COLOR DISPLAY



C1 shiny red



C2 shiny green



C3 shiny pink



MODEL:OX09
SIZE:51-17-140

■ COLOR DISPLAY



C1 shiny purple mix



C2 shiny pink mix



C3 shiny blue mix



MODEL:OX10
SIZE:52-18-140

■ COLOR DISPLAY



C1 shiny blue/mix



C2 shiny grey



C3 shiny red/mix



MODEL:OX11
SIZE:52-18-145

■ COLOR DISPLAY



C1 shiny purple stripe/blue



C2 shiny pink stripe/orange



C3 shiny red



MODEL:OX12
SIZE:49-19-140

■ COLOR DISPLAY



C1 shiny blue



C2 shiny orange



C3 shiny green

ONIX



MODEL:OX14
SIZE:53-17-145

■ COLOR DISPLAY



C1 shiny brown demi



C2 shiny blue



C3 shiny grey



MODEL:OX15
SIZE:56-16-145

■ COLOR DISPLAY



C1 shiny blue



C2 shiny crystal



C3 shiny black



MODEL:OX16
SIZE:54-17-140

■ COLOR DISPLAY



C1 shiny black



C2 shiny dark blue



C3 shiny pink



MODEL:OX17
SIZE:56-18-145

■ COLOR DISPLAY



C1 shiny black/yellow



C2 shiny black/red



C3 shiny black/yellow/blue



MODEL:OX18
SIZE:56-16-145

■ COLOR DISPLAY



C1 shiny black/crystal



C2 shiny blue



C3 shiny blue/green



MODEL:OX19
SIZE:56-16-145

■ COLOR DISPLAY



C1 shiny black



C2 shiny red



C3 shiny blue



Model: OX20



C1



C2



C3



MODEL:OX21
SIZE:55-16-140

■ COLOR DISPLAY



C1 shiny black/crystal



C2 shiny blue/red



C3 shiny black/yellow/blue



MODEL:OX25
SIZE:54-17-140

■ COLOR DISPLAY



C1 matt black



C2 matt silver/black



C3 matt brown



MODEL:OX26
SIZE:52-17-140

■ COLOR DISPLAY



C1 shiny demi



C2 shiny brown/crystal



C3 shiny pink/crystal



MODEL:OX27
SIZE:54-16-140

■ COLOR DISPLAY



C1 shiny green



C2 shiny red



C3 shiny blue



MODEL:OX28
SIZE:53-15-140

■ COLOR DISPLAY



C1 shiny white/demi



C2 shiny black/mix



C3 shiny red/mix



MODEL:OX29
SIZE:54-15-140

■ COLOR DISPLAY



C1 shiny blue mix



C2 shiny purple mix



C3 shiny pink mix



MODEL:OX30
SIZE:54-15-140

■ COLOR DISPLAY



C1 shiny orange demi



C2 shiny blue demi



C3 shiny pink demi



MODEL:OX31
SIZE:54-17-140

■ COLOR DISPLAY



C1 shiny brown



C2 shiny blue



C3 shiny grey



MODEL:OX32
SIZE:54-17-140

■ COLOR DISPLAY



C1 shiny pink



C2 shiny purple



C3 shiny red



MODEL:OX33
SIZE:48-19-140

■ COLOR DISPLAY



C1 shiny black/mix



C2 shiny pink



C3 shiny red/mix



MODEL:OX34
SIZE:53-18-140

■ COLOR DISPLAY



C1 shiny purple mix



C2 shiny brown mix



C3 shiny green mix



MODEL:OX35
SIZE:49-21-140

■ COLOR DISPLAY



C1 shiny black



C2 shiny wine red



C3 shiny purple



MODEL:OX36
SIZE:51-16-140

■ COLOR DISPLAY



C1 shiny blue/black



C2 shiny purple/black



C3 shiny red